

slat

instructions for use

1. Check mains connection, if disconnected.
2. Push main cable through cable entry part of the wall or ceiling bracket and ensure tight seal.
3. Attach wall or ceiling bracket. Pay attention of position „top“. Use the washer gasket with rubberized face against to the wall or ceiling bracket. Seal unused mounting holes.
4. Push silicone-tubes over power lines.
5. Establish ground connection and connect power lines.
6. Hook light housing into notch of the wall or ceiling bracket, press wall or ceiling bracket and tight set screws flush and evenly. Avoid pinched cables.





light technology:

IvyLight-technology
230V Power LED / 3000K
16 W/880 lm
A EEC

technical information:

operating voltage 230V / 50Hz
IP65 protection class
safety class 1
Luminaire is suitable for mounting on normal inflammable surfaces.
CE conformity mark

maintenance:

Disconnect the electrical installation.

Check gaskets and clean or replace them if necessary.

This luminaire contains built-in LED lamps. The lamps cannot be replaced in the luminaire.

dimming:

The luminaire can be dimmed with an approved leading- or trailing edge dimmer. Please contact IP44.de service center for a list of approved dimmers.

care:

Regularly clean luminaire from dirt and deposits. Do not use a high pressure cleaner for cleaning.

Please note care instructions at www.IP44.de.

safety:

We point out that the electric connection of light fixtures has to be done by a certified installer.

We assume no accountability for damages which are a result of non-appropriate mounting or application of the luminaire.

Modifications on the luminaire will result in loss of warranty.