

## IP44.de connect

### instructions for use

1. Check mains connection, if disconnected.
2. Route the connections with the chosen junctions (Y-junction box, H-junction box or plug/socket).
3. All junctions (Y-junction box, H-junction box or plug/socket) may only be installed horizontally, and not vertically.
4. Any junction may only be installed **aboveground** and not underground.
5. The TWISTLOCK technology components snap together noticeably and audible when connected with firm pressure (symbol ›arrow‹ on ›close lock‹) – see figure.
6. Simply turn to release the TWISTLOCK technology components again (symbol ›arrow‹ on ›open lock‹) – see figure.
7. Install luminaires according to instructions for use of the chosen luminaire shot, piek or vic.
8. Sockets, that possibly will not be connected have to be covered by sealing cap socket. Otherwise a tightness according to protection class IP68 can't be ensured.
9. Connect mains connection port with grounded electrical socket.
10. Grounded electrical sockets have to correspond to the essential protection class
11. The mains connection port may not be casted in any case.

#### safety:

We point out that the electric connection of IP44.de connect has to be done by a certified installer.

We assume no accountability for damages which are a result of non-appropriate mounting or application of the components.

Modifications on the components will result in loss of warranty.

