


slat 40 poller

instructions for use

1. Remove baseplate from light-tube.
2. Conduct mains cable through the baseplate.
3. The baseplate has to be screwed on a foundation with the included fixing material; where necessary prepare a drainage system. Ensure a secure position and flushness with FFL (finished floor level).
4. Connect underground cable with cable connector inside the luminaire. Ensure tight seal of the PG fitting.
5. Slide light-tube onto baseplate and tight countersunk head screws flush and evenly. Avoid pinched cables.



installation: Possibility of through wiring
with Y-connector inside luminaire (item no. 55312)

light technology:

IvyLight-technology
230V Power LED / 3000K
system performance: 8 W/180 lm

 EEC

technical information:

operating voltage 230V / 50Hz



protection class



safety class 1



Luminaire is suitable for mounting on normal inflammable
fixing surfaces.



conformity mark

maintenance:

Disconnect the electrical installation.

This luminaire contains built-in LED lamps. The lamps cannot
be replaced in the luminaire.

dimming:

The luminaire can be dimmed with an approved leading- or
trailing edge dimmer. Please contact IP44.de service center
for a list of approved dimmers.

care:

Regularly clean luminaire from dirt and deposits. Do not use a
high pressure cleaner for cleaning.

Please note care instructions at www.IP44.de.

safety:

We point out that the electric connection of light fixtures has
to be done by a certified installer.

We assume no accountability for damages which are a result
of non-appropriate mounting or application of the luminaire.

Modifications on the luminaire will result in loss of warranty.

note: Moist concrete may be highly alkaline and must not
contact the luminaire permanently! Therefore we recommend
to provide a sufficient drainage in the installation area and to
apply the foundation with a special base-coating.